Visual	Operating instruction
	 Lift Big bag by the handles with the tractor forks, Place the vidbag under the big bag, when stabilized. Gradually lowering the fork to pierce the Big bag. Place the big bag above the hopper, Open the valve, and close as soon as the hopper is full, When the big bag is empty, take off Vidbag and try again,. ATTENTION It is imperative to operate Vidbag and Fillsilobag in line with health and safety proceduresand your health and safety statement. Never stand under the load. The Vidbag must be placed on a hard floor or on a rigid support for easy piercing of the bag. Make sure that content of the big bag does not contain lumps. The Vidbag is designed for stationary use the big bag. Use of vidbag is reserved exclusively for drilling and partial or total emptying of the big bag. Lift Big bag by the handles with the tractor forks, Place the vidbag under the big bag, when stabilized. Gradually lowering the fork to pierce the Big bag.